Is Your Motorcycle Ready to Ride?

00.00 mm							
32.00					20000000	22222000	
SS 5 30		600-600 i	e Iı	200000000		200000000000000000000000000000000000000	
SS 5.46	2 2 3 3 4 5	201 8 8 1	. 3333 33	s I 🤏 8	11837648	8 7 8 7	1 888
SSE \$355	46, 7244				A 23. 23		8800

Check the following items before you get on the motorcycle:

Tires Use a gauge to check the air

pressure. Adjust if needed. Also look for signs of damage or excessive wear (page 92).

Spokes & Rims Make sure the spokes are tight. Also check the rims for damage

(page 87).

Leaks

Look under the motorcycle for signs of leaking fluids (fuel,

engine oil).

Engine Oil

Check the level and add oil if

needed (page 61).

Fuel

Check the level and add fuel (page 55) if needed. Also make sure the fuel fill cap is securely fastened.

Drive Chain

Check the condition and slack. Adjust and lubricate if needed. Also check the chain slider for wear and replace if needed (page 97).

Cables

Check the cable housings for wear. Check the fittings for looseness. Replace or tighten as

needed.

Nuts & Bolts Use a wrench to make sure all accessible nuts, bolts, and

fasteners are tight.

Spark Plug

Check for looseness (page 75).