| | FREQUENCY / ITEM | WHICHEVER → COMES FIRST ↓ | | ODOMETER READING [ NOTE (1) ] | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | × 1,000 km | 1 | 6 | 12 | 18 | 24 | 30 | 36 | REFER |
| | | | × 1,000 mi | 0.6 | 4 | 8 | 12 | 16 | 20 | 24 | TO |
| | | NOTE | MONTH | | 6 | 12 | 18 | 24 | 30 | 36 | PAGE |
| | DRIVE CHAIN | | | EVERY 1,000 km (600 mi) I, L | | | | | | | 107 – 111 |
| | DRIVE CHAIN SLIDER | | | | | I | | I | | I | 112 |
| | BRAKE FLUID | NOTE (3) | | | I | I | R | I | I | R | 31 – 33 |
| | BRAKE PAD WEAR | | | | I | I | I | I | I | I | 122 |
| | BRAKE SYSTEM | | | I | | I | | I | | I | 31 – 33, 124 |
| * | BRAKE LIGHT SWITCH | | | | | I | | I | | I | 130 |
| * | HEADLIGHT AIM | | | | | I | | I | | I | – |
| | CLUTCH SYSTEM | | | | | I | | I | | I | 34 |
| | CLUTCH FLUID | NOTE (3) | | | I | I | R | I | I | R | 34 |
| | SIDE STAND | | | | | I | | I | | I | 114 |
| * | SUSPENSION | | | | | I | | I | | I | 113 |
| * | NUTS, BOLTS, FASTENERS | | | I | | I | | I | | I | – |
| ** | WHEELS/TYRES | | | | | I | | I | | I | – |
| ** | STEERING HEAD BEARINGS | | | I | | I | | I | | I | – |