

Loosen the rearview mirror socket bolts.



Remove the windscreen mounting bolts. Slightly pulling up the upper cowl, remove the windscreen by lifting out one side of the windscreen and sliding it out to the side.

Remove the collars and special nuts from the windscreen.



Disconnect the front turn signal connectors.



Remove the following:

- Socket bolts
- Rearview mirror
- Mirror plate
- Rubber cushion

