

NOTICE

- If the engine does not start within 5 seconds, turn the ignition OFF and wait 10 seconds before trying to start the engine again for recovery of battery voltage.
- Extended fast idling and revving the engine can damage the engine, and the exhaust system.

- 1 Turn the ignition switch to the ON position.
- 2 Make sure the transmission to Neutral (Nindicator comes on).

(Using the start button)

Press the start button with the throttle completely closed. Release the start button as soon as the engine starts.

(Using the Kickstarter)

Lightly depress the kickstarter until resistance is felt.

Then let the kickstarter return to the top of its stroke.

With the throttle closed, operate the kickstarter. Kick from the top of the stroke through to the bottom with a rapid, continuous motion.