

5. To set the minute, press the right control button until the desired minute appears.
  - Quick setting — press and hold the right control button until the desired minute appears.
6. Press the left control button when the display reaches the desired minute.  
The display will stop flashing.

If the ignition switch is turned off or no operation is performed for 5 seconds during the time adjustment mode, the clock will be reset.

The clock will be reset AM 1:00 if the battery is disconnected.