

Front/Rear Turn Signal Bulb

▲ WARNING

* The light bulb becomes very hot while the light is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.


CAUTION:

* Wear clean gloves while replacing the bulb.

NOTE:

* Be sure to turn the ignition switch OFF when replacing the bulb.

1. Remove the three screws (1).
2. Remove the turn signal lens (2).



- (1) Screws
- (2) Turn signal lens