


Anti-lock brake system (ABS) indicator (CBF1000A)

This indicator light normally illuminates when the ignition switch is set to ON and is extinguished when the motorcycle is ridden at a speed of more than 10 km/h (6 mph).

If there is a problem with the ABS system, this light flashes and remains on (see page 68).



(1) Anti-lock brake system (ABS) indicator