


## Brake/Tail Light Bulb

1. Remove the two screws (1).
2. Remove taillight lens (2).
3. Remove the bulb (3).
4. Install a new bulb in the reverse order of removal.



- (1) Screws  
(2) Taillight lens  
(3) Bulb