


## Preparation

Before starting, insert the key, turn the ignition switch ON and confirm the following:

- The gearshift is in neutral.  
The relative neutral indicator light illuminates.
- The engine stop switch is set to  (RUN).
- The engine oil pressure indicator is illuminated.
- The ABS indicator light is illuminated (see page 18 – only for CBF500A)

The low oil pressure indicator should go off a few seconds after the engine starts. If the light keeps flash during operation, stop the engine immediately and check the engine oil level.

### NOTICE

Operating the engine with insufficient oil pressure can cause serious engine damage.