

ITEM		FREQUENCY	WHICHEVER →	ODOMETER READING [NOTE(1)]								REFER TO PAGE	
				COMES FIRST ↓	× 1,000 km	1	6	12	18	24	30		36
					× 1,000 mi	0.6	4	8	12	16	20		24
					NOTE	MONTH	6	12	18	24	30		36
	DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)								74-78	
	DRIVE CHAIN SLIDER					I			I		I	79	
	BATTERY					I	I	I	I	I	I	92-94	
	BRAKE FLUID	(NOTE 4)				I	I	R	I	I	R	17-20	
	BRAKE PAD WEAR					I	I	I	I	I	I	89	
	BRAKE SYSTEM				I			I			I	17-20, 91	
*	BRAKE LIGHT SWITCH							I			I	97	
*	HEADLIGHT AIM							I			I	-	
	CLUTCH SYSTEM							I			I	21	
	CLUTCH FLUID	(NOTE 4)					I	I	R	I	I	R	21
	SIDE STAND							I			I	80	
*	SUSPENSION							I			I	79	
*	NUTS, BOLTS, FASTENERS					I					I	-	
**	WHEELS/TYRES							I			I	-	
**	STEERING HEAD BEARINGS					I					I	-	