

MAINTENANCE

page

92 MAINTENANCE

- 92 THE IMPORTANCE OF MAINTENANCE
- 93 MAINTENANCE SAFETY
- 94 SAFETY PRECAUTIONS
- 95 MAINTENANCE SCHEDULE
- 98 TOOL KIT
- 99 SERIAL NUMBERS
- 100 COLOUR LABEL
- 101 ENGINE OIL
- 106 THROTTLE OPERATION
- 107 IDLE SPEED
- 108 COOLANT
- 109 DRIVE CHAIN
- 115 DRIVE CHAIN SLIDER
- 116 FRONT AND REAR SUSPENSION INSPECTION
- 117 SIDE STAND
- 118 WHEEL REMOVAL
- 125 BRAKE PAD WEAR
- 127 BATTERY
- 129 FUSE REPLACEMENT

page

- 132 BRAKELIGHT SWITCH ADJUSTMENT
- 133 BULB REPLACEMENT
- 139 CLEANING**
- 144 STORAGE GUIDE**
 - 144 STORAGE
 - 146 REMOVAL FROM STORAGE
- 147 SPECIFICATIONS**
- 151 CATALYTIC CONVERTERS**
- 152 NOISE CONTROL SYSTEM (AUSTRALIA ONLY)**