

<b>(Ref.No.) Description</b>	<b>Function</b>
(13) RESET button	<p>Use this button for the following purposes.</p> <ul style="list-style-type: none"> <li>• To adjust time</li> <li>• To reset tripmeter</li> <li>• To change unit of speedometer, odometer and tripmeter (E type only)</li> <li>• To change setting of the tachometer red zone indicator activation revolution and indication pattern</li> <li>• To display the total mileage of the odometer when you drive 100,000 kilometers (miles) or more</li> </ul>
(14) SEL button	<p>Use this button for the following purposes.</p> <ul style="list-style-type: none"> <li>• To adjust time</li> <li>• To switch blinking of the immobilizer system (HISS) indicator (except MX type)</li> <li>• To change indication of tripmeter A and B</li> <li>• To change setting of the tachometer red zone indicator activation revolution and indication pattern</li> </ul>