



## HESD Indicator and Malfunction Indicator (MIL)

The HESD indicator (1) and the red malfunction indicator (MIL) (2) lights when there is any abnormality in the HESD (Honda Electronic Steering Damper).

The HESD indicator should also go on for a few seconds and then go off when the ignition switch is turned ON and engine stop switch is at  (RUN).

If the HESD indicator and red malfunction indicator (MIL) lights at any time, reduce speed and take the motorcycle to your Honda dealer as soon as possible.



- (1) HESD indicator
- (2) Malfunction indicator (MIL)