


To select the REV indicator indication pattern:

An indication pattern can be selected from the 9 patterns (page 33).

The indication pattern will be set each time you press the RESET button (1), to select a pattern you like.

To end the setting, press the SEL button.

As you turn off the ignition switch during the presetting procedures, the preset data just before turning off the ignition switch will be registered.



- (1) RESET button
- (2) REV indicator