


HEADLIGHT AIM VERTICAL ADJUSTMENT


Vertical adjustment can be made by turning the screws (1) and (2) in or out as necessary.

Obey local laws and regulations.

Except E, IIIE, VIE, EK, IVEK, VIIEK, U, IIU:



For E, IIIE, VIE, EK, IVEK, VIIEK, U, IIU:



- (1) Screw (low beam)
(2) Screw (high beam)

- (A) Up
(B) Down