

Headlight Switch


The headlight switch (1) has two positions; "OFF" and "ON".

ON: Headlight on.

OFF: Headlight off.

Engine Stop Switch

Your motorcycle is equipped with an engine stop switch (2). At the "OFF" position, the ignition circuit is open. The switch should normally be placed at the "RUN" position. Do not use this switch except to stop the engine in an emergency.



Commutador del faro

El commutador del faro (1) tiene dos posiciones; "ON" y "OFF".

ON: Faro encendido.

OFF: Faro apagado.

Interruptor de parada del motor

Su motocicleta está equipada de un interruptor de parada del motor (2). En la posición "OFF", el circuito del encendido estará abierto. Este interruptor deberá colocarse por lo normal en posición "RUN". No utilice este interruptor salvo en el caso de emergencia.