

BRAKE SHOE WEAR

(Refer to the maintenance precautions on page 66).

The rear brake is equipped with a brake wear indicator.


When the brake is adjusted, a reference mark (1) moves toward an arrow mark (2) attached to the brake arm (3). If the arrow mark aligns with the reference mark, the brake shoes must be replaced.

See your authorized Honda dealer for this service.

NOTE:

- * When the brake service is necessary, see your Honda dealer. Use only genuine Honda parts or its equivalent.

< REAR BRAKE >



(1) Reference mark

(2) Arrow

(3) Brake arm