

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH	6	12	18	24	30	36			
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	107	
AIR CLEANER		NOTE (2)				R			R	93–95	
CRANKCASE BREATHER		NOTE (3)		C	C	C	C	C	C	96	
SPARK PLUGS					R		R		R	104	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	97	
ENGINE OIL FILTER			R		R		R		R	100	
* ENGINE OIL STRAINER SCREEN					C		C		C	100	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	108	
RADIATOR COOLANT		NOTE (5)			I		I		R	33–34, 109	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	