


Headset/speaker Mode Button

If you use the headset, push this button. The display will indicate “” (headset). To hear sound through the speakers, push this button again.

Headset/Speaker
Mode Button



Intercom Volume Control Knob

⚠ WARNING


- ***Some local governments prohibit the operator from using a headset; always obey applicable laws and regulations.***

To communicate with the passenger using the intercom, turn this knob clockwise.

Turning this knob further increases intercom volume. When not using the intercom system, turn off this knob.

NOTE:

- The auto volume control does not function for the intercom system
- Turn this knob only high enough for adequate volume; if turned too high, there may be “feed back” from the fairing speakers.



Front Headset
Terminal

