

MAINTENANCE

AIR CLEANER

Refer to the Maintenance Precautions on page 108.
The numbers are shown in sequence of disassembly.

