


Parking Brake Inspection

1. Stop the engine and put the scooter on its center stand on level ground.
2. Count the number of clicks before the brake starts to take hold by slowly pulling the grip down from the fully returned position.

Parking brake grip free play is:

2–4 clicks

If adjustment is necessary, have the brake adjusted by your Honda dealer for this service.



(1) Parking brake grip