

MAJOR COMPONENTS

(Information you need to operate this motorcycle)

⚠ WARNING

- *If the Pre-ride Inspection (page 44) is not performed, severe personal injury or vehicle damage may result.*

REAR SUSPENSION

Spring preload adjustment:

The rear shock absorber has five adjustment positions for different load or riding conditions.

Remove the right saddlebag (page 40).

