




## Controls & Features

### Parking Brake

#### LEFT HANDLEBAR



(1) lock lever  
(2) parking brake pin

(3) clutch lever/  
parking brake lever  
(A) to lock

The lock lever (1) and parking brake pin (2) on the clutch lever/parking brake lever (3) allows it to be used as a parking brake. To operate, push down and hold the parking brake pin, squeeze the clutch lever/parking brake lever and then lock it with the lock lever. See *Parking* page 70 .

To release the parking brake, squeeze the clutch lever/parking brake lever.

