

Fuses	
Location	109
Replacement	110
G	
Gasoline (see Fuel)	
Gearshift pedal	22
Gearshifting	22, 57
Gear case oil	
Rear final gear case oil	99
H	
Headlight switches	19
Helmet holder	29
High altitude fuel mixture adjustment	93
Hills	
Riding across slopes	72
Riding down hills	70
Riding up hills	63
Stopping on hills	65
Turning on slopes	73
I	
Idle speed adjustment	91
Ignition switch	13
Indicator lamps	
Neutral indicator lamp	21
Reverse indicator lamp	21
Inspection, pre-ride	34
L	
Loading	
Loading guidelines and procedures	38
Weight limits	37
Lubrication (see Engine oil, Gear case oil and differential oil)	