

T

| | |
|--------------------------------|---------|
| throttle | |
| cable | 166 |
| lever..... | 37, 166 |
| tires, | |
| air pressure | 183 |
| flat..... | 219 |
| replacing..... | 188 |
| repairing | 187 |
| thread conditions | 185 |
| tool kit | 138 |
| trailer towing | |
| operational guidelines | 86 |
| weight limits..... | 85 |
| training, rider..... | 76 |
| transporting your ATV..... | 204 |
| tripmeter | 23 |
| trouble, unexpected | 213 |
| troubleshooting, starting..... | 215 |
| turning, | |
| on level ground..... | 112 |
| on hills or slopes..... | 120 |

V

| | |
|---------------------------------------|-----|
| valve clearance..... | 171 |
| vehicle identification no. (VIN)..... | 234 |