


Inspecting the Brake Pads

Check the condition of the brake pad wear indicator wear indicators. The pads need to be replaced if a brake pad is worn to the wear indicator.



- 1. Front** Inspect the brake pads from below the brake caliper.
 - Always inspect both left and right calipers.
- 2. Rear** Inspect the brake pads from the rear left of the motorcycle.

If necessary have the pads replaced by your dealer.

Always replace both left and right brake pads at the same time.