
Storage Equipment

Helmet Holder

Operation Guide

48

The helmet holders is located under the rear seat. The helmet set wire is stored in the tool kit. **D** P. 67



Helmet set wire



Helmet set wire

Helmet D-ring

▶ Use the helmet holder only when parked.

Removing the Rear Seat <->P.68

AWARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.