









Other Adjustments ► Changing the Front Seat Height



- 5. Install the front seat. ▶ P. 69
 - When setting the high seat position: Install the front seat by aligning its recesses with the front side stays and placing its prong on the front centre stay.



Maintenance

