

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 42) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	INITIAL MAINT.	REGULAR MAINT. INTERVAL					Refer to page
			x100km	1.5	10	20	30	40	
			x100mi MONTH	1	6	12	18	24	
* FUEL LINE					I		I	—	
** FUEL STRAINER SCREEN					C		C	—	
* THROTTLE OPERATION					I		I	70-71	
AIR CLEANER	NOTE1			C	C	C	C	60-61	
SPARK PLUG				I	I	I	I	67-68	
* VALVE CLEARANCE			I	I	I	I	I	—	
ENGINE OIL			R	R	R	R	R	62-64	
ENGINE OIL FILTER			R	R	R	R	R	65-66	
* ENGINE OIL STRAINER SCREEN IN DOWN TUBE					C		C	—	
* DECOMPRESSOR SYSTEM			I	I	I	I	I	46	
** ENGINE IDLE SPEED			I	I	I	I	I	69	
DRIVE CHAIN	NOTE1		I,L	Every 500km(300mi) or every 3 month:I,L				73	
DRIVE CHAIN SLIDER				I	I	I	I	74	