

<b>F</b>	
Flooded Engine .....	28
Front Brake Lever Adjustment .....	76
Front Suspension .....	77
<b>Fuel</b>	
Recommended .....	30
Remaining .....	19
Tank Capacity.....	30
<b>Fuel Gauge</b> .....	19
<b>Fuses</b> .....	45, 97
<b>G</b>	
Gasohol.....	115
Gasoline .....	30, 115
<b>H</b>	
Hazard Switch.....	26
Headlight Aim .....	79
Headlight Dimmer Switch.....	26
Helmet Holder .....	31
High Beam Indicator .....	25
High Oil Temperature Indicator .....	24, 82
Honda Contacts.....	118

<b>Horn Button</b> .....	26
<b>I</b>	
Ignition Cut-off System	
Banking Sensor .....	101
Side Stand .....	69
Ignition Key.....	100
Ignition Switch.....	27
Indicators.....	24
Information Record .....	124
Instruments .....	18
<b>L</b>	
Labels.....	7
Load Limits .....	15
Loading Guidelines.....	15
Low Oil Pressure Indicator .....	24, 83
<b>M</b>	
Maintenance	
Fundamentals .....	40
Importance .....	35
Safety .....	36