

Gauges, Indicators & Displays


Odometer/Tripmeter A & B

The odometer (1) shows the total miles or kilometers ridden.

The tripmeter A (2) and tripmeter B (3) show number of miles or kilometers ridden since you last reset the meter.

To select the odometer, tripmeter A or tripmeter B, push the SET button (4).

To reset the tripmeter, push and hold the RESET button (5) for more than 2 seconds when the display is in the tripmeter A or tripmeter B.



- (1) odometer
- (2) tripmeter A
- (3) tripmeter B

- (4) SET button
- (5) RESET button