


## Position Light Bulb



1. Remove the bulb lid. ➤ P. 61
2. Pull off the socket without turning.
3. Pull out the bulb without turning.
4. Install a new bulb and parts in the reverse order of removal.