

N	
Neutral Indicator	31
O	
Odometer	20, 109
Oil	
Engine	52, 65
Other Warning Indications	94
Overheating	91
Oxygenated Fuels	123
P	
Parking	12
Parts Location	16
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL).....	31, 92
Protective Apparel	9
R	
Rear Seat.....	63
Rear Suspension.....	88
Recommended	
Coolant.....	55
Fuel.....	37
Oil	52
Refueling	37
Removal	
Battery.....	60
Clip.....	61
Front Seat.....	62
Rear Seat.....	63
Right Side Cover	64
Repair Kit	95
Reporting Safety Defects	128
Riding Precautions	10
Right Side Cover	64
S	
Safety Labels	7
Safety Precautions.....	9
Shifting Gears	36
Side Stand.....	75
Side Stand Ignition Cut-off System	75
Specifications.....	129
Speedometer	19
Start Button	32, 35
Starting the Engine	35
Steering Lock.....	34