

## Instruments (Continued)


**Torque Control level** → P.56

**S indicator**

CRF1000D

Comes on when the S mode is selected in the AT MODE.

→ P.65



**D indicator**

CRF1000D

Comes on when the D mode is selected in the AT MODE.

→ P.65

**G indicator**

CRF1000D

Comes on when the G switch is turned on. → P.54