


Battery Box Cover



Removal

1. Remove the bolt using the hex wrench provided on the underside of the front seat. ► P. 83
2. Remove the battery box cover by releasing its tab from the guide.

Installation

Install the parts in the reverse order of removal.