

# Servicing Your Honda

---

<i>Service Preparations</i>	
Maintenance Component Locations .....	52
Tools .....	55
Left Side Cover Removal .....	56
Left Fuel Tank Shroud Removal .....	57
Right Fuel Tank Shroud Removal .....	58
Clip Removal .....	59
<i>Service Procedures</i>	
<u>Fluids &amp; Filters</u>	
Fuel .....	60
Engine Oil .....	63
Air Cleaner .....	69
Crankcase Breather .....	72
<u>Engine</u>	
Throttle .....	73
Clutch System .....	76
Valve Clearance .....	78
Engine Idle Speed .....	81
Spark Plug .....	82
Spark Arrester .....	84
<u>Chassis</u>	
Suspension .....	87
Brakes .....	90
Wheels .....	96
Tires & Tubes .....	101
Side Stand .....	105
Drive Chain .....	106
<u>Electrical</u>	
Battery .....	113
Appearance Care .....	118