

G

gap, spark plug	67
gasohol	153
gasoline.....	40
gearing.....	137
guidelines,	
steering damper	135
suspension adjustment	130

H

handlebar inspection.....	105
Honda,	
contacting	161
Rider's Club	163
service manual.....	160

I

identification, vehicle	148
idle speed, engine	61
indicator,	
MIL blink	7
circuit inspection	8
DTC index.....	9
inspection, pre-ride.....	13
instruments	5

L

labels, safety	4
logbook, competition.....	154

M

maintenance,	
after competition	30
before & after competition	30
between motos & practice.....	30
component locations	32
general competition.....	26
importance.....	22
safety	23
schedule.....	24
manual, service.....	160
modifications	3

O

oil,	
engine	49
fork	87
transmission	52
operating instructions	15
operation component locations	6
optional,	
parts list.....	156
sprockets.....	137
oxygenated fuels.....	153

P

pads, brake.....	93
parts, optional	156
personal fit adjustments	139
pinging, engine	40
plug, spark	67
pre-load, rear suspension.....	125
pre-ride inspection.....	13
protective apparel	2

R

rear suspension maintenance.....	125
Rider's Club Honda (USA only).....	163
riding,	
apparel.....	2
basic operation	15
before.....	11
important safety information.....	2
safety precautions.....	2

S

safety,	
a few words about	Safety Messages
important information	2
important precautions.....	2
labels	4
maintenance.....	23
riding precautions.....	16
schedule, maintenance.....	24
seat	33
serial numbers	148
service,	
customer	162
manuals	160
spare parts.....	157
spark knock	40
spark plug,	
maintenance	67
reading.....	133
specifications	149
spring pre-load, rear suspension	125
starting,	
engine	17
troubleshooting.....	145
steering damper,	
adjustment	134
guidelines	135
operation inspection.....	104
steering stem inspection	105
(cont'd)	