This section tells you how to fine tune your CRF for maximum competition performance.

Initial suspension adjustments should be performed after a minimum of 1 hour of easy break-in time.

Optional rear suspension springs are available in order to tailor your CRF specifically for your weight, riding style and course conditions.

Follow the instructions given in the rear suspension sag setting section of *Rear Suspension Adjustments* to determine if your combined rider and sprung machine weight (rider fully dressed for competition and machine filled coolant, oil and fuel levels ready for competition) requires an optional stiffer or softer rear spring. The need for either optional rear spring may need to be balanced by adjusting the left fork air pressure and oil capacity.

Engine Mode Select Button	12
Current Mode	
Mode Selection	120
Front Suspension Adjustments	12
Front Suspension Air Pressure	
Front Suspension Damping	
(Right Fork)	12
Fork Springs (Left Fork)	
Fork Removal	
Right Fork Disassembly	
Damper Oil Change	
Right Fork Assembly	
Fork Installation	13.
Rear Suspension Adjustments	13
Rear Suspension Spring Pre-Load	13
Rear Suspension Damping	13
Rear Suspension Race Sag	139
Suspension Adjustments for	
Frack Conditions	
Suspension Adjustment Guidelines	142
Funing Tips	
Spark Plug Reading	
Steering Damper Adjustment	
Steering Damper Damping	14
Steering Damper Adjustment Guidelines	14'
Chassis Adjustments	
Rear End	
Fork Height/Angle	
Wheelbase	
Gearing	149
Fire Selection for Track Conditions	15
Personal Fit Adjustments	
Control Positioning	
Handlebar Position, Width & Shape	15