


**Odometer [TOTAL] & Tripmeter [TRIP A/B]**

**[SEL]** button switches between the odometer and tripmeters.

- Odometer: Total distance ridden.  
When "-----" is displayed, go to your dealer for service.
- Tripmeter: Distance ridden since tripmeter was reset (press and hold **[SET]** button to reset to 0.0 km/mile at the tripmeter display).  
When "----.-" is displayed, go to your dealer for service.

**Speedometer****Clock (12-hour display)****Fuel gauge**

Remaining fuel when only 1st (E) segment starts flashing:  
approximately 0.42 US gal (1.6 L)

**If the fuel gauge indicator flashes in a repeat pattern or turns off:** **➡ P.90**

