



• Remove the snap ring using the special tool.
Snap ring pliers: 07914-SA50001

• Master cylinder inspection

BRAKE CALIPER

BRAKE PAD REPLACEMENT

