

# INDEX

---

SERVICE INFORMATION	
COOLING SYSTEM .....	6-1
CRANKCASE/TRANSMISSION.....	11-1
CRANKSHAFT/PISTON/CYLINDER .....	12-1
CYLINDER HEAD/VALVE.....	8-1
ELECTRIC STARTER .....	18-1
ENGINE REMOVAL/INSTALLATION .....	7-1
FRAME/BODY PANELS/EXHAUST SYSTEM .....	2-1
FRONT WHEEL/SUSPENSION/STEERING .....	13-1
FUEL SYSTEM .....	5-1
HYDRAULIC BRAKE .....	15-1
IGNITION SYSTEM.....	17-1
LIGHTS/METERS/SWITCHES .....	19-1
LUBRICATION SYSTEM.....	4-2
MAINTENANCE .....	3-1
REAR WHEEL/SUSPENSION .....	14-1
SERVICE RULES .....	1-2
SHIFT FORK/SHIFT DRUM.....	11-4
SHOCK ABSORBER .....	14-8
SIDE STAND .....	3-22
SIDE STAND SWITCH.....	19-17
SPARK PLUG.....	3-6
SPECIFICATIONS .....	1-4
SPEEDOMETER/SPEED SENSOR.....	19-8
STARTER CLUTCH.....	10-4
STARTER MOTOR.....	18-4
STARTER RELAY SWITCH.....	18-10
STEERING HEAD BEARINGS .....	3-25
STEERING STEM .....	13-21
SUSPENSION.....	3-23
SUSPENSION LINKAGE .....	14-11
SWINGARM .....	14-15
SYSTEM TESTING .....	6-3
TACHOMETER.....	19-9
THERMOSTAT.....	6-10
THROTTLE OPERATION .....	3-4
THROTTLE SENSOR .....	17-8
TOOLS .....	1-14
TORQUE VALUES .....	1-11
TRANSMISSION .....	11-6
TROUBLESHOOTING	
ALTERNATOR/STARTER CLUTCH .....	10-1
BATTERY/CHARGING SYSTEM .....	16-3
CLUTCH/GEARSHIFT LINKAGE.....	9-3
COOLING SYSTEM .....	6-2
CRANKCASE/TRANSMISSION.....	11-2
CRANKSHAFT/PISTON/CYLINDER .....	12-2
CYLINDER HEAD/VALVE .....	8-2
ELECTRIC STARTER.....	18-2
FUEL SYSTEM .....	5-3
FRAME/BODY PANELS/EXHAUST SYSTEM .....	2-1
FRONT WHEEL/SUSPENSION/STEERING .....	13-2
HYDRAULIC BRAKE .....	15-2
IGNITION SYSTEM.....	17-3
LUBRICATION SYSTEM.....	4-3
REAR WHEEL/SUSPENSION .....	14-2
TURN SIGNAL LIGHT .....	19-4
TURN SIGNAL RELAY .....	19-18
VALVE CLEARANCE .....	3-7
VALVE GUIDE REPLACEMENT .....	8-12
VALVE SEAT INSPECTION/REFACING .....	8-13
WATER PUMP.....	6-11
WHEELS/TIRES .....	3-25
WIRING DIAGRAM .....	20-1