

Always check air pressure when your tyres are “cold.” If you check air pressure when your tyres are “warm”—even if your motorcycle has only been ridden for a few miles—the readings will be higher. If you let air out of warm tyres to match the recommended cold pressures, the tyres will be underinflated.

The recommended “cold” tyre pressures are:

Front	150 kPa (1.50 kgf/cm <sup>2</sup> , 22 psi)
Rear	150 kPa (1.50 kgf/cm <sup>2</sup> , 22 psi)

### **Inspection**

Whenever you check the tyre pressures, you should also examine the tyre treads and sidewalls for wear, damage, and foreign objects:

Look for:

- Bumps or bulges in the side of the tyre or the tread. Replace the tyre if you find any bumps or bulges.
- Cuts, splits or cracks in the tyre. Replace the tyre if you can see fabric or cord.
- Excessive tread wear.

Also, if you hit a pothole or hard object, pull to the side of the road as soon as you safely can and carefully inspect the tyres for damage.